



# H51

## Manual Z-Controller



The TPT manual Z-Controller allows you to operate your bond head manually. The Bond is being made automatically as soon as the needle touches the surface. This makes bonding on different heights and with various loop lengths much faster.

- + manual bonding
- + loop shape control at any time
- + no bond height adjustment needed
- + quick setup

